

Vehicle Test Matrix

Manufacturer	Model	Wheelbase	WB Length	Floor Length	Innotrax Full Floor	Body Mounted 3rd Point	Crew Cab Part Floor	Innotrax Flat Floor	Suspension Kit (Required for Flat Floor)	Low Profile Rail Installation	Surface Rail Installation	Heavy Duty Rail Installation	Solo Anchors Installation	Witness Report Available
Citroen	Jumper/Relay 2006 -	SWB	3000	2670	Y	GR	Y	N	N	N	N	N	N	Y
		MWB	3450	3120										
		LWB	4035	3705										
Citroen	Jumpy/Dispatch 2007 -	SWB	3000	2254	Y	GR	N	N	N	N	N	N	N	Y
		LWB	3122	2584										
Fiat	Ducato 2006 -	SWB	3000	2670	Y	GR	Y	N	N	N	N	N	N	Y
		MWB	3450	3120										
		LWB	4035	3705										
Fiat	Scudo 2007 -	SWB	2824	2250	Y	N	N	N	N	N	N	N	N	Y
		LWB	3224	2580										
Ford	Transit 2013 -	MWB	3300	2949	Y	B	Y	Y	N	N	N	N	N	Y
		LWB	3750	3399										
		XLWB	3750	4107										
Ford	Transit Custom 2012 -	SWB	2933	2555	Y	GN	Y	N	N	N	N	N	N	Y
		LWB	3300	2720										
Iveco	Daily 2009-2014	SWB	3000	3000	Y	GR	Y	Y	Y	N	N	N	N	Y
		MWB	3300	3560										
		LWB	3950	4560										
Iveco	Daily 2014 -	SWB	3000	2600	N	GN	N	Y	N	N	N	N	N	N
		MWB	3520	3540										
		LWB	4100	4680										
		XLWB	4100	5125										
Mercedes	Sprinter 2006 -	SWB	3250	2600	Y	GR	Y	Y	Y	N	N	N	N	Y
		MWB	3665	3265										
		LWB	4325	4300										
		XLWB	4325	4700										
Mercedes	V Class, Vito, Viano 2003 -	SWB	3200	2422	Y	N	N	N	N	N	N	N	N	Y
		MWB	3200	2670										
		LWB	3430	2850										
Nissan	NV400 2015 -	SWB			N	N	N	N	N	N	N	N	N	N
		MWB												
		LWB												
		XLWB												
Nissan	Primastar 2001-2014	SWB	3198	2400	Y	N	Y	N	N	N	N	N	N	Y
		LWB	2598	2800										
Nissan	Primastar 2014 -	SWB			N	N	N	N	N	N	N	N	N	N
		LWB												
Peugeot	Boxer 2006 -	SWB	3000	2670	Y	GR	Y	N	N	N	N	N	N	Y
		MWB	3450	3120										
		LWB	4035	3705										
Peugeot	Expert 2007 -	SWB	3000	2254	Y	N	N	N	N	N	N	N	N	Y
		LWB	3122	2584										
Renault	Master 2010 -	SWB	3182		Y	B	Y	Y	N	N	N	N	N	Y
		MWB	3682	3733										
		LWB	4332	3733										
Renault	Traffic 2001-2014	SWB	3100	2400	Y	W	N	N	N	N	N	N	N	Y
		LWB	3500	2800										
Renault	Traffic 2014 -	SWB			N	N	N	N	N	N	N	N	N	N
		LWB												
Vauxhall	Movano 2010 -	SWB	3080	2710	Y	B	N	N	N	N	N	N	N	Y
		MWB	3580	3210										
		LWB	4080	3710										
Vauxhall	Vivaro 2001-2014	SWB	3100	2400	Y	N	Y	N	N	N	N	N	N	Y
		LWB	3500	2800										
Vauxhall	Vivaro 2014 -	SWB			N	N	N	N	N	N	N	N	N	N
		LWB												
Volkswagen	Crafter 2006 -	SWB	3250	2600	Y	GR	Y	Y	Y	N	N	N	N	Y
		MWB	3665	3265										
		LWB	4325	4300										
		XLWB	4325	4700										
Volkswagen	T5 / Transporter 2003 -	SWB	3000	2543	Y	W	Y	N	N	N	N	N	N	Y
		LWB	3400	2943										

Vehicle Test Matrix

Manufacturer	Model	Also Made By	Also Called	Wheelbase	WB Length	Floor Length	Innotrax Full Floor	Body Mounted 3rd Point	Crew Cab Part Floor	Innotrax Flat Floor	Suspension Kit (Required for Flat Floor)	Low Profile Rail Installation	Surface Rail Installation	Heavy Duty Rail Installation	Solo Anchors Installation	Witness Report Available	
Citroen	Jumper/Relay 2006 -	Fiat Peugeot	Ducato Boxer	SWB	3000	2670	VCA-ESJ198157 (26-11-2009)	GR	VCA-ESP294693 (04/07/2014)	N	N	N	N	N	N	Y	
				MWB	3450	3120	VCA-ESH177809 (06-06-2007)										
				LWB	4035	3705	TUV-45SG0563-03 (11/11/2010)										
Citroen	Jumpy/Dispatch 2007 -	Fiat Peugeot Toyota	Scudo Expert Proace	SWB	3000	2254	TUV-45SG0563-03 (11/11/2010)	GR	N	N	N	N	N	N	N	Y	
				LWB	3122	2584											
Fiat	Ducato 2006 -			SWB	3000	2670	VCA-ESJ198157 (26-11-2009)	GR	VCA-ESP294693 (04/07/2014)	N	N	N	N	N	N	Y	
				MWB	3450	3120	VCA-ESH177809 (06-06-2007)										
				LWB	4035	3705	TUV-45SG0563-03 (11/11/2010)										
Fiat	Scudo 2007 -			SWB	2824	2250	TUV-45SG0563-03 (11/11/2010)	N	N	N	N	N	N	N	N	Y	
				LWB	3224	2580											
Ford	Transit 2013 -			MWB	3300	2949	VCA-ESQ318565 (Await Report)	B	N	VCA- (Await Report)	N	N	N	N	N	Y	
				LWB	3750	3399	TUV-Await Report										
				XLWB	3750	4107	UTAC-Await Report										
Ford	Transit Custom 2012 -			SWB	2933	2555	VCA-ESQ323129 (Await Report)	GN	VCA-ESQ323129 (Await Report)	N	N	N	N	N	N	Y	
				LWB	3300	2720	TUV-Await Report										
Iveco	Daily 2009-2014			SWB	3000	3000	VCA-ED052800 (04/08/2006)	GR	VCA-ESP294693 (04/07/2014)	VCA-ESL220826 (07/05/2010)	Y	N	N	N	N	Y	
				MWB	3300	3560	TUV-45SG0563-03 (11/11/2010)										
				LWB	3950	4560											
Iveco	Daily 2014 -			SWB	3000	2600	N	B	N	VCA-ESR356479 (Await Report)	N	N	N	N	N	N	
				MWB	3520	3540											
				LWB	4100	4680											
				XLWB	4100	5125											
Mercedes	Sprinter 2006 -	Volkswagen	Crafter	SWB	3250	2600	VCA-ESG 078521 (12/9/2006)	GR	VCA-ESP294693 (04/07/2014)	VCA-ESJ202549 (13/03/2009)	Y	N	N	N	N	N	Y
				MWB	3665	3265											
				LWB	4325	4300											
				XLWB	4325	4700											
Mercedes	V Class, Vito, Viano 2003 -	Mercedes	Viano	SWB	3200	2422	TUV-45SG0563-03 (11/11/2010)	N	N	N	N	N	N	N	N	Y	
				MWB	3200	2670											
				LWB	3430	2850											
Nissan	NV400 2015 -			SWB			N	N	N	N	N	N	N	N	N	N	
				MWB													
				LWB													
				XLWB													
Nissan	Primastar 2001-2014			SWB	3198	2400	VCA-ED052800 (14/08/2003)	N	VCA-ESP294693 (04/07/2014)	N	N	N	N	N	N	Y	
				LWB	2598	2800	TUV-45SG0563-03 (11/11/2010)										
Nissan	Primastar 2014 -			SWB			N	N	N	N	N	N	N	N	N	N	
				LWB													
Peugeot	Boxer 2006 -			SWB	3000	2670	VCA-ESJ198157 (26-11-2009)	GR	VCA-ESP294693 (04/07/2014)	N	N	N	N	N	N	Y	
				MWB	3450	3120	VCA-ESH177809 (06-06-2007)										
				LWB	4035	3705	TUV-45SG0563-03 (11/11/2010)										
Peugeot	Expert 2007 -			SWB	3000	2254	TUV-45SG0563-03 (11/11/2010)	N	N	N	N	N	N	N	N	Y	
				LWB	3122	2584											
Renault	Master 2010 -	Nissan Vauxhall Opel	NV400 Movano Movano	SWB	3182		VCA-ESQ318566 (Await Report)	B	VCA-ESP294693 (04/07/2014)	VCA-ESQ321889 (Await Report)	N	N	N	N	N	Y	
				MWB	3682	3733	VCA-ESL220825 (07/05/2010)										
				LWB	4332	3733	TUV-45SG0563-03 (11/11/2010)										
Renault	Traffic 2001-2014			SWB	3100	2400	VCA-ED052800 (14/08/2003)	W	N	N	N	N	N	N	Y		
				LWB	3500	2800	TUV-45SG0563-03 (11/11/2010)										
Renault	Traffic 2014 -	Vauxhall	Vivaro	SWB			N	N	N	N	N	N	N	N	N	N	
				LWB													
Vauxhall	Movano 2010 -			SWB	3080	2710	VCA-ESL220825 (07/05/2010)	B	N	N	N	N	N	N	N	Y	
				MWB	3580	3210											
				LWB	4080	3710											
Vauxhall	Vivaro 2001-2014			SWB	3100	2400	VCA-ED052800 (14/08/2003)	N	VCA-ESP294693 (04/07/2014)	N	N	N	N	N	Y		
				LWB	3500	2800	TUV-45SG0563-03 (11/11/2010)										
Vauxhall	Vivaro 2014 -			SWB			N	N	N	N	N	N	N	N	N	N	
				LWB													
Volkswagen	Crafter 2006 -			SWB	3250	2600	TUV-45SG0563-03 (11/11/2010)	GR	Y	Y	Y	N	N	N	N	Y	
				MWB	3665	3265											
				LWB	4325	4300											
				XLWB	4325	4700											
Volkswagen	T5 / Transporter 2003 -			SWB	3000	2543	VCA-ED052800 (14/08/2003)	W	VCA-ESP294693 (04/07/2014)	N	N	N	N	N	Y		
				LWB	3400	2943	TUV-45SG0563-03 (11/11/2010)										